



Kid Galaxy Morphibians Explorer Controller Battery Replacement

Replacing the batteries of the remote controller.

Written By: Rusbell Gonzalez





TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Batteries



- Turn the controller over to the backside and locate the battery cover screw.

Step 2



- The battery cover 8.0mm Phillips #2 screw is on the bottom left handle. There is a plastic washer holding the screw to the cover, so completely loosen the screw, but do not remove.

Step 3



- Once the screw is removed lift the battery cover up from the controller.

Step 4



- Remove the 2 AA batteries.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 08:51:40 PM.